

DINAIR[®] ONE

QUICK START GUIDE




Hold the Airbrush Like an airbrush



Easy to find
your best
angle

Virtual Makeup Brush - Sizes



INSTANTLY CHANGE BRUSH SIZES... BY CHANGING AIRBRUSH DISTANCES

- Replaces All Your Traditional Brushes
- Eliminate Brush Cleaning
- Eliminate Brush Contamination
- Faster Application than Traditional Brushes
- Only Air and Makeup Touch the Skin

All-In-ONE Airbrush Compressor



Charge for 1 hour before using. Can run while plugged into charger

WARNING: Only charge with the supplied battery charger.

Makeup Lever Control (Learn this!)

The position of the airbrush lever determines the amount of makeup being released. Suggested positions are based on the nozzle tip being freshly brushed and polished clean.


Best makeup is done between 0-5

12:00

Lever Position*

(Barely Move Lever)

- 1 - 2 Eye Liner
- 1 - 2 Brows
- 2 - 3 Shadow
- 3 - 4 Blush
- 2 - 4 Conceal
- 4 - 6 Foundation
- 10+ Rinsing



Swap Airbrushes in Seconds



Push spring clasp collar down to release airbrush.

Tanning • Hair Color • Fantasy


Dinair ONE
with Optional
TZ Airbrush



Large Cup for
Big Projects.


Pick your Brush Size

Practice keeping your airbrush at the same distance. Use water to learn the right distance and motion.



Distance & Brush Size - Practice

Attach Guide to Airbrush for practice exercises. Practice Correct Distance & Brush Size



The Distance Guide will help you to rehearse holding the tip of the airbrush the correct distance from the face. It adjust from about 1" out to 5".

Deep Clean Spray Tip with Brush



Listen To Your Airbrush

Listen to the "light wind" sound of air only. Then as you slightly pull the lever back you will begin hear the soft shower" sound of water. The lever is barely pulled back. Most of dinair makeup is done with the lever barely pulled back.



Feel the Air

Feel the Warm Air, and the Cool Water. Try blowing air on your hand or arm at a foundation brush distance. Then pull the lever back slightly until you hear the water sound and you will feel a slight cooling by the very light coverage of water. Practice spraying so lightly that the water evaporates on contact. Several very light passes could become a beautiful, natural Dinair makeup coverage

Deep Clean Inside Airbrush

Between uses: Put on Cleaning Caps with Cleaner.



Open Bottles and Manage Drops

FLIP TOP



1. Open Flip Top.
2. Insert a small Pin into the spout.
3. Pierce through the safety seal.



Hold straight Up & Down, (90°) to pour.

DROPPER CAP



Do not let mixing ball fall into dropper tip and block dropper tip while trying to put drops of makeup in airbrush cup.

1. Catch mixing balls on bottle shoulder by keeping bottle at pouring angle of 30°-45°.
3. Only squeeze bottle gently.
4. If bottle resists squeezing, tap the of the bottle bottom on a table to dislodge the mixing balls.

Shake bottles until you hear sound of mixing balls and continue to shake bottle for 5 to 10 seconds. Pinch bottom of bottle if needed to loosen mixing balls.



Gluten Free



Vegan



Cruelty Free



Hypoallergenic



Non-Comedogenic



Silicone Free

No Silicones, Parabens or Talc • No Setting Powders, Rub Proof & Water Proof

We Like to Help

Dinair's Award-Winning Customer Service Team can answer any and all of your questions,

M-F, 8AM-5PM. SAT, 10AM-2PM. PST

Call us or Visit Online!

AirbrushMakeup.com | 800.785.4770 | help@dinair.com

AirbrushHelp.com